

# HOMEFACTORS

## FURNISHING CONSULTANTS

Homefactors Ltd, P O Box 2661, Buckhurst Hill, Essex IG8 1SN

Tel 020 8203 3166

Email: [info@homefactors.co.uk](mailto:info@homefactors.co.uk)

Website: [www.homefactors.co.uk](http://www.homefactors.co.uk)

## HOW TO MEASURE FOR YOUR NETS

Nets are usually measured and hung inside the window recess. Measure accurately using a wood or metal rule (not a cloth tape which may stretch). Use either Imperial (inches) or Metric. Do not make any allowances for fullness as we allow for this when making up the nets.

Decide at what point you want the net to start at the top. This is where the wire will be fitted. Measure the width at this point.

Decide at what point you want the net to finish at the bottom. This is usually where the net will just rest above the cill. Measure the drop from the point where the wire will be hung at the top, to the point where you want the net to finish at the bottom.

The diagram on the right indicates suggested width and drop starting and stopping points based on a typical window frame. The size and style of your window frame may require you to decide on a slightly different place for your width and drop starting and stopping points.

